

Disney Princess



2019 EYEGLASSES COLLECTION





Disney
FROZEN

Disney
FROZEN



◀ **DPAA071C12** 43 □ 15 - 120
FLEX HINGES



◀ **DPAA073C08** 47 □ 16 - 125
FLEX HINGES

C12



◀ **DPAA076C08** 43 □ 15 - 130
FLEX HINGES

C10



Disney FROZEN



◀ **DPAA077C69** 42 □ 17 - 120
FLEX HINGES

C70



◀ **DPAA078C66** 44 □ 15 - 120
FLEX HINGES

C68



C71



◀ **DPAA079C65** 45 □ 15 - 120
FLEX HINGES

C71



Disney FROZEN



◀ **DPAA080C66** 47 □ 15 - 120
FLEX HINGES

C72



◀ **DPAA081C07** 47 □ 16 - 130
FLEX HINGES

C12



◀ **DPAA082C12** 42 □ 16 - 120
FLEX HINGES





Disney
FROZEN

Disney FROZEN



◀ DPAA084C12

46 □ 17 - 125
FLEX HINGES



◀ DPAA085C08

43 □ 16 - 120
FLEX HINGES



◀ DPAA086C08

45 □ 17 - 125
FLEX HINGES

C12





Disney
FROZEN

Disney FROZEN



◀ **DPAA087C06** 47 □ 16 - 125
FLEX HINGES

C08



◀ **DPAA089C06** 45 □ 15 - 120
FLEX HINGES

C08



◀ **DPAA090C08** 46 □ 16 - 125
FLEX HINGES

C12



Disney FROZEN



◀ **DPAA092C66** 43 □ 17 125
FLEX HINGES



◀ **DPAA093C12** 44 □ 16 - 125
FLEX HINGES

C62



◀ **DPAA094C08** 45 □ 16 - 125
FLEX HINGES

C12



Disney FROZEN



◀ **DPAA095C08**

46 □ 16 125

FLEX HINGES



◀ **DPAA097C10**

45 □ 15 - 120

FLEX HINGES

C36



◀ **DPAA098C08**

46 □ 127- 125

FLEX HINGES

C36





Disney
FROZEN

Disney FROZEN



◀ **DPAA099C06** 47 □ 15 - 125
FLEX HINGES

C14



◀ **DPAA101C08** 43 □ 15 - 120
FLEX HINGES

C65



◀ **DPAA102C65** 44 □ 15 - 120
FLEX HINGES

C08



Disney FROZEN



◀ **DPAA104C36** 43 □ 18 - 120
FLEX HINGES

C68



◀ **DPAA105C65** 44 □ 15 - 120
FLEX HINGES

C68



◀ **DPAA107C68** 46 □ 17 - 125
FLEX HINGES

C72



Disney FROZEN



◀ **DPAA109C36** 44 □ 16 - 120
FLEX HINGES

C68



◀ **DPAA111C66** 46 □ 15 - 120
FLEX HINGES

C68



◀ **DPAA114C65** 46 □ 17 - 120
FLEX HINGES

C70



Disney FROZEN



◀ **DPAA115C36** 44 □ 17 - 125
FLEX HINGES

C68



◀ **DPAA117C66** 45 □ 15 - 120
FLEX HINGES



◀ **DPAA118C68** 46 □ 15 - 120
FLEX HINGES

C72

